


NOTE: WHEN ONLY THE PIEZO/MONO JACK IS CONNECTED, THE MIX POT CONTROLS THE MAXIMUM LEVEL OF THE PIEZO SIGNAL. WHEN THE MAGNETIC/STEREO JACK IS CONNECTED, THE MIX POT IS DISABLED.



MAGNETIC/STEREO OUTPUT-  
 WHEN USED WITH A MONO CABLE, THIS OUTPUT PROVIDES A PASSIVE SIGNAL FROM THE MAGNETIC PICKUPS ONLY.  
 WHEN USED WITH A STEREO (TRS) CABLE, TIP OUTPUTS PASSIVE MAGNETIC SIGNAL; RING OUTPUTS BUFFERED PIEZO SIGNAL.

PIEZO/MONO OUTPUT-  
 USE MONO CABLE ONLY.  
 WHEN ONLY THIS JACK IS CONNECTED, A BUFFERED AND MIXED COMBINATION OF THE MAGNETIC AND PIEZO SIGNALS IS PRODUCED.  
 WHEN BOTH JACKS ARE USED, THIS OUTPUT WILL PRODUCE THE BUFFERED PIEZO SIGNAL ONLY; THE MAGNETIC SIGNAL IS DIVERTED TO THE MAGNETIC/STEREO OUTPUT.

<b>ERNEBALL MUSIC MAN</b>			
SILHOUETTE PIEZO GUITAR HSH CONTROL FUNCTION DIAGRAM			
REV	DRAWN BY JHW	APPROVED BY -	DATE 11-26-01
SCALE NONE	TOLERANCE	N/A	PART NO.